

## PCB IN - PCB OUT AIRCONDITIONING SPARE PARTS



BOX 10 BOX 9 KFR-50LW/BPY-R 1 KFR105DL/SN1Y-B (AUT) 1 LSQWRF60M/D 1 MDV-D280W/S-810 1 MDVD71DL/N1 1 KFR26G/N2Y-M1  
MSM1-09HRN2 2 KFR26GW/Y-A 1 KFR50GW/I1Y(S) MSG21HRN2 1 KFR160DL/SN1Y-B (AUT) MDV-D280/S-810S 2 KFR-28GW 1  
KFR35W/IBPN2-110 1 KFR120L/SDN1Y-J 1 KFR-26GW/I1BPY 1 KFR48G/Y-E1 MSC-18HRN1 1 KFR-32G/DUY DISPLAY 1  
KFR35G/I1BPN2Y MSG-12HRIN2 IN 2 KFR32G/BP2N1Y-GI9B(C2) 1 KFR36GW/I1Y (S) MSG-12HRN1 IN 1 KFR50GW/I1Y (S) MSG21HRN2  
1 KFR160T2/SN1Y 1 KFR61GW/I1Y MSG-30HRN2 24 1 KFR105Q/N2SY 1 KFR53GW/Y-C (T) MSB-21HR 1 KFR-26GW/I1BPY MSG12  
HRIN2 2 KFR35G/I1BPN2Y MSG-12HRIN2 1 KFR70W-21E 1 POWER-DIP(DZMK) 2 KFR61W/I1Y 1 KFR50G/N1FY-V1 1

?????????: ??? ????????????? ????  
????

[?????? ?? ?? ??????](#)

?????????